



DE

Gebrauchsanweisung

L3

Art.-Nr. 70510

GB

Instruction for Use

L3

Article No. 70510

FR

Mode d'emploi

L3

Art. N° 70510

NL

Gebruikshandleiding

L3

Art.-Nr. 70510

Dear Client,

Congratulations for choosing one of our quality products. Please follow these instructions carefully and keep them with you.

Product description

The innovative L3 mobile from ISOTRONIC. Battery-operated, mobile and highly effective.

For maximum detection and repelling of domestic animals from areas where they are not desirable, e.g. for hiking, fishing, camping, hunting and in the garden, sand boxes, ponds or in the vicinity of cars or boats. Universal application.

You won't have to get upset by unwanted visits on your premises. Immediately ready for use, no power connection and no assembly necessary.

Without the need for bothersome cabling, this new device from ISOTRONIC can now be immediately used in all imaginable places. Place. Switch on.

Operating mode

New electronics means minimal power consumption. The device emits high-frequency sounds at intervals and a light signal in addition.

Technical data

Battery-operated:	2 x AAA Micro (not included)
Effective range:	approx. 30 m ² indoor and 6 m radius outdoor
Frequency:	7 – 14 kHz +/- 10 %
Volume control:	infinite adjustment
Light:	LED ON-/OFF
Operating temperature and humidity:	- 20C° to +50 C° and ≤ 90% R.H.
Storage temperature and humidity:	- 5C° to +50 C° and ≤ 90% R.H.

Replacement of the batteries

1. Remove the housing cover.
2. Remove the old batteries from its fitting.
3. Insert a new batteries size Micro (AAA). When doing so, mind the correct polarity as shown on the bottom inside the battery fitting.
4. Reattach the casing cover to the casing body.

General information

1. Electric appliances, packaging material etc. should be kept away from children.
2. Dispose packaging and worn out material correctly and in an environmentally friendly way.
3. Do only pass on the device including the operation manual.
4. Subject to change of design and technical data without notice for the sake of constant product improvement.

Safety instructions

Important: Damage caused by not adhering to the operating instructions is not covered by guarantee. ISOTRONIC accepts no liability whatsoever for any resulting consequent damages.

- Only operate the device at its intended voltage.
- In case of repairs, only use original spare parts, to avoid serious damage.
- Repairs or other works, e.g. changing a fuse, etc. may only be carried out by an appropriately trained, skilled person.
- It must be noted that operator or connecting errors lie outside the influence of ISOTRONIC and we cannot accept any liability for resulting damages.
- Always check whether the device is suitable for the respective place where you intend using it.
- This appliance is not intended for use by persons (including children aged from 8 years) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Attention: Important battery notice



Instructions for battery disposal:

Batteries are subject to legal provisions. After use they must therefore be returned to the point of sale or to a collecting point of public facilities for harmful substances. Batteries may never be disposed as household waste, in the yellow sack or other. Dispose of batteries only when completely discharged into a waste batteries collecting container and take precautions against short circuit (e.g. by masking the poles).

Guarantee

We grant a two year guarantee for this device. Guarantee includes repair of all defects that were not caused by defective material or fabrication mistakes. Since ISOTRONIC has no influence on correct and appropriate assemblage and operation it is obvious that guarantee applies only on completeness and proper condition. ISOTRONIC takes on neither liability nor guarantee for damages or consequential damages in connection with this product. This applies especially when the device was altered or repaired, when circuits were changed or non-original spare parts were used or when damage was caused by false or negligent operation or abuse.

**Distributed by
Conrad Electronic SE**

Status: 07/14

Environmental protection notice



■ At the end of its life span this product may not be disposed as normal household waste but must be disposed of at a collecting place for recycling of electrical and electronic equipment. The icon on the product, in the manual, or on the packing points to this fact.

The materials are recyclable according to their labelling. Through reusing, material recycling, or other forms of utilisation of old devices you make an important contribution to the protection of the environment.

Please ask the local administration for the responsible waste disposal centre.